

# Earth Shield® Flexible PVC Waterstop Labyrinth (PVC702) Jobsite Installation Guide

1. Attach labyrinth waterstop to formwork using double-headed nails.
2. Carefully remove the formwork after the first concrete pour, being careful to not displacing the labyrinth waterstop.
3. Cut the now-protruding nail, leaving the labyrinth waterstop partially embedded in the first concrete pour.
4. Place the second pour of concrete.

*For welding, fabrication, placement, execution, and quality assurance please follow all procedures stated in Earth Shield Master Specification Section 03250.*

